



### **Steps for initial setup of InTemp data loggers**

1. Go to [www.InTempConnect.com](http://www.InTempConnect.com) and set up an account
2. Set roles and user privileges and alerts as needed
3. Download InTemp app on a mobile device with IOS or Android
4. Log into the InTemp app with your InTempConnect cloud credentials
5. Connect to InTemp CX5000 Gateway with the InTemp mobile app
6. Set up the InTemp CX5000 Gateway using the app to connect to local Wi-Fi or Ethernet
7. Once the InTemp CX5000 Gateway is connected to the cloud, connect InTemp CX data loggers to the CX5000 Gateway

### **Links to the Onset website that may be useful**

Quick Start for the InTemp CX Temperature Logger (CX40x)

<https://www.onsetcomp.com/intemp/resources/quick-start-intemp-cx-temperature-logger-cx40x/>

Quick Start for the InTemp CX600 and CX700 Series Logger

<https://www.onsetcomp.com/intemp/resources/quick-start-intemp-cx600-and-cx700-series-loggers/>

Quick Start for the InTemp CX5000 Gateway

<https://www.onsetcomp.com/intemp/resources/intemp-gateway-quick-start-guide/>

InTemp Connect Quick Reference

<https://www.onsetcomp.com/intemp/resources/intempconnect-quick-reference-guide/>

Using InTemp with 21 CFR Part 11 Systems

<https://www.onsetcomp.com/intemp/resources/21-cfr-part-11-compatibility/>